



## General Description

The RM-MX141M is the optional IR Remote Control for MX141M Media Strip Mixer.

For ideal operation, a line of sight between the remote control and the sensor on the unit is required. The IR remote does only control the basic functions of the media player section and as such adds convenience to the operation, but does not replace the front panel control on the unit itself.

**Transport Controls:** In Media play mode, the 4 transport control buttons allow you to start and pause a track, and further skip to the next track or back to the beginning of the current track. These controls are inactive in FM mode.

**Source button:** Toggles the program source between Media play and FM Tuner. If FM Tuner is chosen as the program source, the display's FM Mode indicator is lit while the media replay

related indicators are disabled. Further, the media replay related user interface elements are disabled and the functional assignment of the navigation controls are changed.

**Mute button:** Toggles between muted and un-muted output of the media player.

**Volume control (up/down):** Allows you to set the required audio volume of the media player.

**FM preset station buttons:** Allows to remotely activate the stored FM station presets. These buttons only work in FM mode and are disabled in Media play mode. Note that manual tuning via the IR remote control is not possible.

CR2025 Button Battery is included.

**Disclaimer:** Cloud Electronics accepts no responsibility for anything at all as a result of this modification being performed.